


# InteliNano NT<sup>®</sup> Plus

## Fast User Guide

### Typical wiring diagram



### Dimensions

Case dimensions: 118mm x 108mm x 40mm  
Panel Cutout: 96mm x 96mm

**WARNING!**  
If D+ is not used, connect this terminal to battery positive!









### Accessing the setup mode

Ensure the engine is stopped and the controller is in Manual mode (green LED above button **Auto** is turned off).

If you have not configured the custom initialization (init) screen then press and hold **Stop** button, then briefly press **▲** button and then **Auto**.





If you have already created your own init screen then press and hold **Stop** button and then briefly press **▲**, the custom init screen will appear, keep holding the **Stop** button. Then press **▼** to switch LCD to default init screen, and then press **Auto**.







To move up and down in the setup menu use **▲** and **▼** buttons. Press **Start** button to select or **Stop** button to exit.

	<b>Basic settings</b>		<b>Output settings</b>
	<b>Engine parameters and protections</b>		<b>Input settings</b>
	<b>Generator protections</b>		<b>ECU setting</b>
	<b>AMF(Auto Mains Failure) settings</b>		<b>Info</b>

### Outputs and inputs





Output code	Output source	Type	Terminal assignment
<b>O00</b>	<b>Not Used</b>	binary	T04, T05, T06, T07, T08, T09
<b>O01</b>	<b>Starter</b>	binary	T04
<b>O02</b>	<b>Fuel Solenoid</b>	binary	T05, T06, T07, T08, T09
<b>O03</b>	<b>Stop Solenoid</b>	binary	T05, T06, T07, T08, T09
<b>O04</b>	<b>Alarm</b>	binary	T04, T05, T06, T07, T08, T09
<b>O05</b>	<b>GCB Close/Open</b>	binary	T04, T05, T06, T07, T08, T09
<b>O06</b>	<b>MCB Close/Open</b>	binary	T04, T05, T06, T07, T08, T09
<b>O07</b>	<b>Ready To Load</b>	binary	T04, T05, T06, T07, T08, T09
<b>O08</b>	<b>Prestart</b>	binary	T04, T05, T06, T07, T08, T09
<b>O09</b>	<b>ECU Power Relay</b>	binary	T04, T05, T06, T07, T08, T09
<b>O10</b>	<b>Choke</b>	binary	
<b>O11</b>	<b>Glow Plugs</b>	binary	

	Normally Open Contact – output		Normally Open Contact – input button
	Normally Closed Contact – output		Normally Closed Contact – output

User curves			
	I21	I23	I25
	VDO Level %	VDO 5 Bar	VDO 40-120 °C
	Datcon Level %	VDO 10 Bar	VDO 50-150 °C
		Datcon 5 Bar	Datcon High °C
		Datcon 7 Bar	Datcon Low °C
		Datcon 10 Bar	
	Not selected	Not selected	Not selected

Input code	Input source	Type	Terminal assignment
<b>I00</b>	<b>Not Used</b>	binary	T07, T11, T12, T13, T14, T15
<b>I01</b>	<b>Emergency Stop</b>	binary	T07, T11, T12, T13, T14, T15
<b>I02</b>	<b>Remote Start/Stop</b>	binary	T11
<b>I03</b>	<b>Remote Start And Load</b>	binary	T11
<b>I04</b>	<b>Access Lock</b>	binary	T07, T11, T12, T13, T14, T15
<b>I05</b>	<b>AMF Blocked</b>	binary	T07, T11, T12, T13, T14, T15
<b>I06</b>	<b>MCB Feedback</b>	binary	T07, T11, T12, T13, T14, T15
<b>I07</b>	<b>GCB Feedback</b>	binary	T07, T11, T12, T13, T14, T15
<b>I10</b>	<b>External Warning 1</b>	binary	T07, T11, T12, T13, T14, T15
<b>I11</b>	<b>External Warning 2</b>	binary	T07, T11, T12, T13, T14, T15
<b>I12</b>	<b>External Warning 3</b>	binary	T07, T11, T12, T13, T14, T15
<b>I13</b>	<b>External Shutdown 1</b>	binary	T07, T11, T12, T13, T14, T15
<b>I14</b>	<b>External Shutdown 2</b>	binary	T07, T11, T12, T13, T14, T15
<b>I15</b>	<b>External Shutdown 3</b>	binary	T07, T11, T12, T13, T14, T15
<b>I20</b>	<b>Low Fuel Level</b>	binary	T07, T11, T12, T13, T14, T15
<b>I21</b>	<b>Fuel Level Analog</b>	analog	T13, T14, T15
<b>I22</b>	<b>Low Oil Pressure</b>	binary	T07, T11, T12, T13, T14, T15
<b>I23</b>	<b>Oil Pressure Analog</b>	analog	T13, T14, T15
<b>I24</b>	<b>High Coolant Temperature</b>	binary	T07, T11, T12, T13, T14, T15
<b>I25</b>	<b>Coolant Temperature Analog</b>	analog	T13, T14, T15

## Setpoints


Use  and  buttons to move or change value.  button to select setpoint or confirm changes and  button to go back.

Basic settings		
Setpoint code	Setpoint name	
B01	Nominal Voltage Ph-N	80 – 480 V
B02	Nominal Voltage Ph-Ph	80 – 600 V
B03	Nominal Frequency	50 Hz (1), 60 Hz (2)
B04	Connection Type	Mono Phase (1), SplitPhase (2), 3Ph3Wire (3), 3Ph4Wire (4)
B05	Units Format	Metric unit format (1), US unit format (2)
B06	AMF Function	Disable (1), Enable (2)
B07	Zero Power Mode Delay	0-360 min
B08	Light Tower Mode	Disable (1), Enable (2)
B09	Nominal Current	1 – 1000 A
B10	CT Ratio	1 – 5000 A













Engine parameters and protections		
Setpoint code	Setpoint name	
E01	Prestart Time	0-600 s
E02	Maximum Cranking Time	0-60 s
E03	Cooling Time	0-3600 s
E04	Oil Pressure Shutdown	0-10 Bar
E05	Coolant Temperature Shutdown	0 -150 °C
E06	Battery Undervoltage	8 – 40 V
E07	Warning Maintenance	0 – 10000 h
E08	Oil Pressure Starter Disengagement	Disable (1), Enable (2)
E09	Choke Time	0 – 3600 s
E10	Minimal Stabilization Time	1 – 300 s










Generator protections		
Setpoint code	Setpoint name	
G01	Generator Overvoltage Shutdown	G02 – 200 %
G02	Generator Undervoltage Shutdown	0 - G01 %
G03	Generator Overfrequency Shutdown	G04 – 130 %
G04	Generator Underfrequency Shutdown	0 – G03 %
G05	Generator Short Circuit Shutdown	100 – 500 %
G06	Generator Short Circuit Delay	0 – 10,00 s




















AMF(Auto Mains Failure) settings		
Setpoint code	Setpoint name	
A01	Emergency Start Delay	0 – 600 s
A02	Mains Return Delay	1 – 3600 s
A03	Mains Overvoltage	A04 – 150 %
A04	Mains Undervoltage	50 – A03
A05	Mains Overfrequency	A06 – 150 %
A06	Mains Underfrequency	50 – A05 %

To apply all changes return to the main setup menu and restart the controller by pressing the  button.

## Alarms and Events

Events	
	Mains Return
	Mains Fail
	Manual Start
	Remote Start
	AMF Start
	Manual Stop
	Remote Stop
	AMF Stop
	Auto On
	Auto Off
	Power On
	Island Operation

Warnings	
	Warning Maintenance
	Low Battery
	Low Fuel Level
	External Warning 1
	External Warning 2
	External Warning 3
	ECU Communication Error
	MCB Fail
	Mains CCW Rotation

Shutdowns	
	Emergency Stop
	Overspeed
	Underspeed
	Low Oil Pressure
	High Coolant temperature
	External Shutdown 1
	External Shutdown 2
	External Shutdown 3
	GCB Fail
	Generator Overvoltage
	Generator Undervoltage
	Generator Overfrequency
	Generator Underfrequency
	Generator CCW Rotation
	Start Fail
	Stop Fail
	Battery Flat
	Voltage Autodetect
	Generator Short Circuit

## ECU

For ECU configuration use PC software NanoEdit. For more details see IntelliNano AMF Reference Guide.

### Technical data

Power supply range	6-36 VDC
Power supply drop-out immunity	100 ms
Power consumption	35 – 295 mA
Zero Power Mode consumption	52 - 344 µA

Operating temperature	-20... 70 °C
Operating humidity	95 % non-condensing (IEC/EN 60068-2-30)
Protection degree (front panel)	IP65 with GASKET 4x405 only IP50 without gasket
Storage temperature	-30... 80 °C

Binary outputs (up to 6)	
Low current outputs (4)	500 mA
High current output (2)	6 A (long term) / 10 A (short term) (L≤500mH)
Total output current	10 A (long term) / 16 A (short term) (L≤500mH)

Binary inputs (up to 6)	
Input resistance	1,5 kΩ
Closed contact voltage	<2 V
Open contact voltage	>3,5 V


Suppression diode is strictly recommended!

Analog inputs (up to 3)	
Galvanic insulation	Not insulated
Electrical range	0 - 2500 kΩ
Resolution	0,1 Ω
Precision	2 % ± 3 Ω

Generator/Mains measurements	
Measurement input	1ph gen. voltage, 1ph current, 3ph mains voltage
Measurement type	True RMS
Voltage range	480 V Ph-Ph (277 V Ph-N)
Max. measured voltage	340 V Ph-N
Voltage accuracy	1 %
Frequency range	40 – 70 Hz
Frequency accuracy	1 %
Current range	0 - 5 A
Current accuracy	2% True RMS

Charging alternator preexcitation circuit	
Excitation current	100 mA
Charging fail threshold	80 %

**Typical wiring diagram of AMF application**



**Typical wiring diagram of MRS application**

